



Warranty Instructions

(Perkins engines - CIS Countries)

(1) Operation & Maintenance Manual (OMM), should be delivered to customer by Original Equipment Manufacturer (OEM). Perkins distributor can provide it as an electronic file, upon customer official request, which shows he has not received it via OEM.

Customer has to study the OMM and it should only do what is considerable as low level maintenance (no intrusive works) in OMM, especially in “Maintenance Interval Schedule” section.

Note: Valve lash adjustment and Fuel Injector Test/Change is already intrusive work, which means untrained technician should not undertake.

(2) Considering high sulfur and water contamination in fuel, and some harsh conditions, some service intervals such as listed below, should be done sooner:

- Fuel tank water and sediment drain every day (fuel tank should be remain empty, or to be filled fully at night to prevent any air humidity/moisture condensation into fuel);
- Oil, oil filter and water separator change every 150 hrs;
- Fuel filter and air filter (outer) change every 250 hrs;
- Turbocharger inspect every 1000 hrs;
- Crankcase breather (Canister) replace every 250 hrs. (if fitted);
- Radiator clean every 6 month;
- After-cooler core clean every 6 month (if fitted);
- Cooling system coolant change every year;
- Fuel injector test/change every 1500 hrs. (by trained personnel of Perkins distributor).





(3) Customer is committed to observe following points:

- Not repair engine/parts while it is in warranty period;
- Not remove/install parts (except fast moving parts and what are explained in Maintenance Interval Schedule);
- Using Perkins genuine parts;
- Not change engine application;
- Using correct grade and quality of fuel, oil, anti-freeze, etc.;
- Not using machine/engine in not defined working condition;
- Not taking extra power from engine;
- Do not make changes in engine structure;
- Not adding/removing components/systems which have effect of engine;
- Following engine maintenance instructions in OMM and record what he did;
- Informing local Perkins dealer about machineries powered by Perkins they are importing/producing/distributing in each territory;
- Providing necessary information about machineries and owners/end-users.

(4) The standard warranty policy allows for a maximum shelf life of 48 months before sale to the first end-user. The new product warranty period shall start no later than 48 months from the dispatch date from the Perkins factory. Engines dispatched from the Perkins factory and are not put into service within 48 months will no longer be considered for warranty.

(5) Accepting or rejecting warranty is being recognized by Perkins or its dealer based on Perkins guidelines for its dealer and training courses passed by distributor's personnel.

